

4850 Southway St. S.W. Canton, Ohio 44706

330-477-7719 1-800-686-4331

Fax: 330-477-2905

www.cantonchairrental.com

10' Wide Canopy Install Instructions

- Step 1: Assemble the frame as in the diagram.
 - a. Assemble the perimeter first by sliding two 5' poles together to make a 10' pole. Then slide the 10' poles into the corner brackets and locking them into place with the snap buttons.
 - b. Connect the rafters to the corner brackets and the center cluster and lock them into place with the snap buttons.
- Step 2: Lay the canopy over the frame.
- Step 3: Insert the legs into the bottom corner brackets and lock into place using the snap buttons.
- Step 4: Attach the tent to the frame by clipping the snap at each tent corner to the eyebolt on the leg posts.
- Step 5: Secure the tent to the frame by using the white straps with the plastic clips.
- Step 6: Position stakes about 3' to 3.5' from the canopy coming out in a straight line from each of the diagonal corners. You will have a total of 4 stakes for this canopy set-up.
- Step 7: Place the B-ring end of the canopy anchoring straps on the ground at the position that the stake will be driven in. Insert the pointed end of the stake in the center of the hole of the B-ring and drive the stake down a full ¾ the length of the stake. Only 6" to 8" inches of the stake should remain above ground.
- Step 8: Attach the opposite end of the anchoring strap to the eyebolt on the canopy frame. Tighten the strap. (DON'T OVER TIGHTEN THE STRAPS, FOR THIS WILL CAUSE STAKES TO LOOSEN AND PULL OUT OF THE GROUND)





