

Canopy Tent Instructions

- Step 1: Spread the top flat on the ground in the general region where you would like the tent, keeping it as square as you can.
- Step 2: Position stakes about 3' to 3.5' from tent coming out in a straight line from the brass grommets. Corners will get 2 stakes and middles will get one stake.
- Step 3: Pound stakes down about half the length of one stake (2').
- Step 4: Assemble the legs for your tent by doing the following:
There are a total of 9 short poles and 10 long poles.
You will need to make 8 legs and 1 center pole.
Legs consist of 1 short + 1 long, center consists of 2 long + 1 short pushed together.
- Step 5: Place one leg for each brass grommet around the tent. Once you have completed that, pick one corner to start at. Place the leg through the grommet and stand the leg where two stakes would cross if you made two lines coming back towards the tent. Have the other person tie one rope to each stake. Corners will have 2 ropes and middles will have one rope. Continue the same process for remaining corners, doing all corners first.
- Step 6: Place center pole through the hole in the middle of the tent and tie the ropes to the pole. (Most tents will have this rope, if your tent does not, proceed to the next step.)
- Step 7: Place remaining middle legs through the brass grommets and tie ropes to their stakes. Once all legs and center pole are in and ties off, take sledgehammer and pound stakes down to tighten the tent up. **DON'T OVER POUND STAKES, FOR THIS WILL CAUSE STAKES TO LOOSEN AND PULL OUT OF THE GROUND**

