



Canton Chair Rental 4850 Southway St SW Canton, OH 44706
330-477-7719 * 1-800-686-4331 * Pager 330-966-4308

Coffee Makers (14 amps)

Operating Tips:

1. Fill coffee maker to desired level with COLD water.
2. Add coffee according to manufacturer's recommendations or chart below.
3. Plug coffee maker into outlet. Keep in mind these units should be on their own 20 amp circuit. We recommend that you do not use an extension cord. If you are going to use an extension cord, please make sure it is heavy duty, at least a 12 gauge, 25' extension cord.
4. Light goes on when coffee is done.
5. Remove coffee grounds when coffee has finished brewing.

Cleaning Instructions:

1. Rinse coffee maker before returning.
2. NEVER IMMERSE COFFEE MAKER IN WATER.

Brewing Time (Approximate):

30-60 cups	60 minutes
90-100 cups	90 minutes

***We suggest 1 minute per cup**

Coffee Equivalents:

Number of cups	Coffee measure
30	1 $\frac{3}{4}$ -2 $\frac{3}{4}$ cups
55	3 $\frac{1}{2}$ -4 $\frac{1}{2}$ cups
100	6-8 cups

***Note: One pound of coffee is equal to 4.75 cups of ground coffee.**

*These are recommendations. You can also review the back of your coffee can for instructions.