

Canton Chair Rental

4850 Southway St SW Canton, OH 44706
330-477-7719 • 1-800-686-4331 • Pager 330-966-4308



Hot Box Operating Instructions

How to install unit:

1. Place cabinet near warm ovens. Do NOT place cabinet in drafty areas or near ventilating systems.
2. Plug end into proper wall outlet (120 volts, 2000 watts, 16.6 amps, 60 hertz)
***Keep in mind, each box should be on its' own 20 amp circuit for each box. We recommend that you do not use an extension cord. Plug directly into the outlet. If you are going to use an extension cord, please make sure it is heavy duty, at least a 12 gauge, 25' extension cord.**

How to Hold:

1. Push switch to HEAT.
2. Turn Air Thermostat to No. 10.
3. Preheat cabinet for 30 minutes.
4. Turn Air Thermostat to temperature needed.
5. Put food in cabinet.

NOTE: Proper food holding temperature is 140 degrees or higher.

The outer thermometer does not always read accurately. Please use internal thermometer provided!

To Turn Unit Off:

1. Push switch off.

Cleaning Instructions:

1. Wipe up spills as soon as possible.
2. Wipe down inside and outside of cabinet. Wash trays with soap and water or through the dishwasher before returning to Canton Chair Rental.
3. Please return all parts supplied with box to avoid additional charges!
Internal hanging thermometer
Trays