



Canton Chair Rental

4850 Southway St SW Canton, OH 44706

330-477-7719 • 800-686-4331

After Hours Pager: 330-737-1227

www.cantonchairrental.com

NON-ELECTRIC HOT BOX

Operating Instructions

1. Open the vent on the top of the hot box.
2. Place four (4) sternos in each corner and ignite the fuel. Add sternos as needed.
3. Four sternos will heat the hot box to 160-170°F and will burn for approximately two hours.
4. When finished, extinguish the flames and let the sternos cool before discarding them.